


## Finding the Rack Charger Serial Number

The Rack Charger Serial Number can be identified in three (03) ways.

01. On the inside panel of the Charging Compartment
02. On the Electrical Control Panel of the Power Control Compartment
03. On the external panel near the Cable Gland



The Serial Number starts with CR20T000\*\*\*M



**NOTE:** The Serial Number is a critical part of all the processes as all the records, transactions are monitored based on serial number. It is advised to record the Serial Number for reference purposes.